

Touch Screen disinfecting procedure

QSM-0359

Changelog: 03/21/020 Original QSM

Important precautions before cleaning your Touch Dynamic product

- ☑ Turn off the power to the system and disconnect the power cable.
- ☑ Select non-abrasive cleaning cloths only. The best choice is a microfiber cloth.
- ☑ Never spray or pour the disinfecting liquid directly onto the product. Always spray it onto the cloth, and make sure no liquid is dripping from the cloth.

Recommended disinfection products by WHO and tested by Touch Dynamic	Benefits	Necessary precautions
Isopropyl alcohol 70%-75% (diluted with water)	Single procedure	Flammable. No heat or fire in the vicinity
Diluted (1:99, 1% or less) bleach (not recommended if your touch screen has Anti-Glare (AG) coating . Cannot be used on screen protectors	Requires cleaning after application	Adequate ventilation

Cleaning/disinfecting procedure

1. Turn off the power and disconnect the power cord. Ensure there is no fire or heat in the vicinity, if you are using alcohol. Ensure there is adequate ventilation if you use bleach solution.
2. Dampen a clean, microfiber cloth with your chosen disinfectant. Do NOT spray the disinfectant directly onto the system. Ensure there is no liquid dripping from the cloth.
3. Disinfect the surfaces of the product starting with the touch screen, as it is the area that is touched the most.
4. Repeat step 3 if you are using the bleach solution, but this time use another clean cloth dampened with clear water. Ensure no water is dripping from the cloth
5. Let the system dry before reconnecting power.

Do NOT use any other products to clean the system